



## Universal Remote control operation Meerkat 50 C4 (2011 onwards)



Please note the universal remote functions are as below for the Zuma Meerkat 50 C4

---



This button is used to **enable** the ignition circuit.

Turn the key on. Press this button before starting the engine using the start switch.

---




This button is the remote **kill** switch.

Use this button the switch off the engine remotely.  
(It is also possible of course, to turn off the engine via the kill switch on the handlebars and/ or by turning the key to the off position)

---



- This button **disables** the ignition circuit (if pressed before attempting to start the bike it will appear to start and run for a few seconds and then cut out).

If you press this **blue** button by mistake you need to press  OR turn ignition key off and back on, to be able to start the engine again.